


T-type adapter


《ABSTRACT》

◆ There are the T-type conversion adapter of the LEMO、BNC、SMA and N-type.

◆ Please contact us about the type, price etc of no information in this document.



◆ The symbol (P),(J) used as connector names for BNC etc
is that J means a jack which typically used to mount on panels
P means a plug which typically used to attach to co-axial cable.



KAIZUWORKS CORPORATION
9-18 HIGASHIMATSUBARA HAKONEGASAKI MIZUHOMACHI
NISHITAMAGUN TOKYO 190-1222 JAPAN
Tel : 042-568-0866 Fax : 042-568-0867
E-mail kaizuwks@kaizuworks.co.jp Homepage <http://www.kaizuworks.co.jp>